

Personal Computer  
**MZ-80B**

Programming Utility

**SHARP**

#### NOTICE

The MZ-80 series of sophisticated personal computers is manufactured by the SHARP CORPORATION. Hardware and software specifications are subject to change without prior notice; therefore, you are requested to pay special attention to version numbers of the monitor and the system software (supplied in the form of cassette tape or mini-floppy disk files).

This manual is for reference only and the SHARP CORPORATION will not be responsible for difficulties arising out of inconsistencies caused by version changes, typographical errors or omissions in the descriptions.

This manual is based on the SB-1500 series monitor and the SB-7000 series Floppy DOS.

# — CONTENTS —

	U/PROM
<b>PROM FORMATTER</b> .....	1
Activation of the PROM Formatter .....	1
<b>PROM WRITER FORMATS</b> .....	3
BNPF .....	3
B10F .....	4
HEXADECIMAL .....	5
BINARY .....	6
Performance Boards of Various Companies .....	7
<b>PROM FORMATTER COMMANDS</b> .....	9
File Input/Output Commands .....	9
Y (Yank file) Command .....	9
S (Save file) Command .....	9
CY (Yank disk) Command .....	10
CS (Save disk) Command .....	10
Formatting Commands .....	11
P (Punch) Command .....	11
R (Read) Command .....	11
Other Commands .....	12
M (Memory dump/modify) Command .....	12
V (Verify) Command .....	13
\ (DOS) Command .....	13
# (Change printer mode) Command .....	13
& (Clear) Command .....	13
? (Disp free area) Command .....	14
! (Return) Command .....	14
Format Commands .....	14
<b>PROM FORMATTER (SB-7501) COMMANDS &amp; MESSAGES</b> .....	16
	U/PLOTTER
<b>EXAMPLE OF PLOTTER CONTROL APPLICATION</b> .....	1
Interface Card .....	1
Plotter Control Program .....	1
1. Conditions for linkage with a BASIC program .....	1
2. Linkage conditions when an error occurs .....	2
3. Use of external subroutines .....	2
4. Plotter control codes .....	2
5. Program outline .....	3
Command Table .....	6
Outline of the BASIC Program .....	7
Sample Program (Plotter Control Routines) .....	10
BASIC Main Program .....	19

PROM

1	PROM FORMATTER
1	Activation of the PROM Formatter
3	PROM WRITER FORMATS
3	BNPF
4	B10F
5	HEXADECIMAL
6	BINARY
7	Performance Boards of Various Companies
9	PROM FORMATTER COMMANDS
9	The Input/Output Commands
9	Y (Yank file) Command
9	S (Save file) Command
10	CY (Yank disk) Command
10	CS (Save disk) Command
11	Formatting Commands
11	P (Punch) Command
11	R (Read) Command
12	Other Commands
12	M (Memory dump/modify) Command
13	V (Verify) Command
13	/ (DOS) Command
13	# (Change printer mode) Command
13	& (Clear) Command
14	? (Disp free area) Command
14	! (Return) Command
14	Format Commands
16	PROM FORMATTER (SB-7501) COMMANDS & MESSAGES

UPLOTTER

1	EXAMPLE OF PLOTTER CONTROL APPLICATION
1	Interface Card
1	Plotter Control Program
1	1. Conditions for linkage with a BASIC program
2	2. Linkage conditions when an error occurs
2	3. Use of external subroutines
2	4. Plotter control codes
3	5. Program outline
6	Command Table
7	Outline of the BASIC Program
10	Sample Program (Plotter Control Routines)
19	BASIC Main Program




# PROM FORMATTER

The rapid advances in LSI technology have allowed the functions of a computer's CPU to be concentrated onto a single semiconductor chip. These microprocessors are becoming ever more sophisticated, while at the same time they are becoming less expensive. As a result, the range of fields in which microprocessors are being utilized is growing rapidly. One subject of great importance to the development of new device applications is that of developing efficient application programs; it is not too much to say that the quality of the application program determines how well a newly developed device performs.

On the other hand, developments in LSI technology have also stimulated efforts to develop low cost, large capacity memory elements (RAM and ROM). The increased availability of PROMs which are erasable with ultraviolet rays has had a particularly strong influence on the development of devices which incorporate microprocessors.

The procedure which is most suitable for efficiently developing application programs is to create an object file from a source file created through assembly programming using an assembly language, then to reassemble it after debugging. The function of the PROM formatter is to load one or more object programs created with the assembler and linker, then to output it to a paper tape punch after converting it to PROM writer format.



Functions of the PROM formatter

It also allows programs which are written in different formats to be input from a reader for storage on disk and enables conversion of programs to the required format for output on paper tape or the like.

## —Activation of the PROM Formatter—

Entering PROM **CR** while in the DOS command entry mode activates the PROM formatter. Commands may be entered as soon as activation is completed.

The following formats are provided for in the PROM formatter:

## 1. BNPF

- Britronics
- Intel
- Takeda Riken

## 2. B10F

- Takeda Riken

## 3. HEXADECIMAL

- Britronics
- Takeda Riken
- Minato Electronics

## 4. BINARY

- Britronics


0000

12A0

FF00

Monitor
Floppy DOS
PROM formatter
Free area
Stack area
Reserved

PROM formatter memory map



Functions of the PROM formatter

## —Activation of the PROM Formatter—

Entering PROM  while in the DOS command entry mode activates the PROM formatter. Commands may be entered as soon as activation is completed.


# PROM WRITER FORMATS

PROM writers are provided in many formats by different companies. This section discusses forms which are converted by the PROM formatter; refer to the individual PROM writer manuals for details.

The examples in the figures include the file name "AAA", the address "0000", and the data "5C", "BD" and "27". The leader section for the start of punched output and the trailer section for the end of punched output are created automatically.

## —BNPF—

### Britronics (Format A)




- The file name is punched in ASCII code (if one is specified). (Using the character "B" as a file name will result in incorrect identification of the beginning of data.)
- **CR** and **LF** are punched in ASCII code.
- The space code (20H) and the byte of data at the address specified for "RAM from?" are punched in BNPF format. The address is incremented successively.
- **CR** and **LF** are punched after each 6 items of data are punched in the BNPF format.
- Punching is performed in BNPF format up to the address specified for "to?".

### Intel (Format D)

- This is the same as the Britronics format. The BNPF format is one which has a relatively high degree of standardization; thus, the PROM formatter can also be used with devices other than those which are discussed in this manual.

## Takeda Riken (Format E)




- The "\$" mark, which denotes the file name, is punched in ASCII code.
- The file name is punched in ASCII code (if one is specified).
- **CR** and **LF** are punched. The "\$" mark is regarded as denoting the beginning of a comment statement; the end of a comment statement is denoted with an **LF** code.
- The "#" mark (which indicates the beginning of an address) is punched, followed by the first three digits of the address specified for "PROM address?". The separator between the address and the data is punched as ".".
- The data item at the address specified for "RAM from?" is punched in BNPF format. The address is incremented successively.
- **CR** and **LF** are punched after each 6 items of data are punched in the BNPF format.
- A tape leader stop mark ")" is punched after the data has been punched up to the address specified for "to?".

Note: Care must be taken to ensure that characters which act as control characters (B, ., \$, #, etc.) are not used when a file name is specified. (Otherwise, incorrect operation will result.)

## —B10F—


## Takeda Riken (Format F)



- Except for the NP section, this is the same as Takeda Riken's BNPF format.
- The B10F format corresponds to the BNPF format in that 1 = P and 0 = N.


## —HEXADECIMAL—

### Britronics (Format B)




- The file name is punched in ASCII code (if one is specified).
- The "CTRL/A" mark (01H) indicating the beginning of data is punched.
- **CR** and **LF** are punched.
- The data item at the address specified for "RAM from?" is punched as a 2-digit ASCII code, then a space code is punched.
- **CR** and **LF** are punched after 16 bytes of data have been punched.
- Data is punched up to the address specified for "to?".

### Takeda Riken (Format G)



- The "\$" mark, which denotes the file name, is punched in ASCII code.
- The file name is punched in ASCII code (if one is specified).
- After **CR** and **LF** are punched (followed by the address specification mark "#" and 3 digits of the address specified for "PROM address?"). The separator "." is punched.
- The space code is punched, followed by the 2-digit ASCII code for the data at the address specified for "RAM from?". The separator "." is punched after the data item.
- **CR** and **LF** are punched after 16 bytes of data have been punched.
- Data is punched up to the address specified for "to?", at which point the tape leader stop mark " ) " is punched.


## Minato Electronics (Format H)



- The file name is punched in ASCII code when file name is specified.
- The start-of-data mark " [ " is punched.
- The address designation mark " # " is punched, followed by a 3-digit ASCII code for the address specified for "PROM address?".
- A space code is punched, then the data at the address specified for "RAM from?" is converted to a 2-digit ASCII code and punched.
- 16 combinations of space codes and data items are punched, then **CR** and **LF** are punched.
- The end of data mark " ] " is punched after data has been punched up to the address specified for "to?".

## —BINARY—

### Britronics (Format C)



- In the binary format, the 4-bit mark section and the 4-bit data section are expressed together as one character (8 bits). The mark section is punched as the upper 4 bits of the paper tape, while the data section is punched as the lower 4 bits.
- The file name is punched in ASCII code (if one is specified). Specifications which result in a "3" in the upper 4 bits of the ASCII code file name are not permitted. Such specifications will result in incorrect operation, since incorrect determination that the lower 4 bits of the file name are an address will result.
- Three binary digits for the address specified for "PROM address?" are punched in the lower 4 bits. The address designation mark ("3") is punched in the upper 4 bits.
- A data mark ("1") is punched in the upper 4 bits and data at the address specified for "RAM from?" is punched in the lower 4 bits.
- Data is punched 4 bits at a time (with the upper and lower 4 bits punched in alternation) up to the address specified for "to?".
- Check sum marks ("5") are punched in the upper 4 bits, followed in alternation by check sum data in the lower 4 bits.



**—Performance Boards of Various Companies—** (Note: Consult the various manufacturers for details.)

**a) Intel**

2716  
2732  
8748/8741  
3621, 3602, 3622, 3602A, 3622A, 3604, 3624, 3604A, 3624A, 3605, 3625, 3605A, 3625A, 3628, 3608,  
3604AL-6, 3604AL  
8702A/1702A  
8708/8704/2708/2704  
8755A

**b) Britronics**

Company	Element
Intel	3602 A / 22 A, 3604 A / 24 A, 3604 A L / 24 L, 3605 / 25, 3608 / 28
Intersil	5600 / 10, 5603 A / 23, 5604 / 24, 5605 / 25
Fujitsu	7055, 7051, 7052, 7058, 7053, 7059, 7054, 7057
Monolithic Memory	5330 / 6330, 5331 / 6331, 5300 / 6300, 5335 / 6335, 5336 / 6336, 5308 / 6308, 5309 / 6309, 53134 / 63134, 53135 / 63135, 5305 / 6305, 5306 / 6306, 53137 / 63137, 53141 / 63141, 5340 / 6340, 5341 / 6341, 5348 / 6348, 5349 / 6349, 5350 / 6350, 5351 / 6351, 5352 / 6352, 5353 / 6353, 5380 / 6380, 5381 / 6381, 5384 / 6384, 5385 / 6385, 5386 / 6386, 5387 / 6387
Harris	7602 / 03, 7610 A / 11 A, 7620 A / 21 A, 7640 A / 41 A, 7640 A R / 41 A R, 7642 / 43, 7644, 7646 R / 47 R, 7648 / 49, 7608, 7680 / 81, 7680 R / 81 R, 7680 P / 81 P, 7680 R P / 81 R P, 7683, 7684 / 85, 7684 P / 85 P, 7686 / 87, 7686 R / 87 R, 7686 P / 87 P, 7686 R P / 87 R P
Fairchild	93417 / 27, 93436 / 36, 93438 / 48, 93452 / 52
National Semiconductor	54 / 74 S 387, 54 / 74 S 287, 54 / 74 S 470, 54 / 74 S 471, 54 / 74 S 570, 54 / 74 S 571, 77 / 87 S 295, 77 / 87 S 296, 54 / 74 S 473, 54 / 74 S 472, 54 / 74 S 572, 54 / 74 S 573
NEC	403 D, 406 D
Raytheon	29660 / 61, 29600 / 01, 29612 / 13
Signetics	82 S 114 / 115, 82 S 126 / 127, 82 S 130 / 131, 82 S 140 / 141, 82 S 136 / 137, 82 S 180 / 181, 82 S 2708, 82 S 184 / 185, 82 S 190 / 191
Texas Instruments	54 / 7488 A, 54 / 74 S / 88, 54 / 74 S 288, 54 / 74 S 470, 54 / 74 S 71, 54 / 74 S 73, 54 / 74 S 72, 54 / 74 S 75

**c) Minato Electronics**

Adaptable to all PROMs.

# d) Takeda Riken

## MOS Type

Element	Bit configuration, capacity (words x bits = capacity)	Maker name											
		Okidenki	Toshiba	NEC	Hitachi	Fujitsu	Mitsubishi	Intersil	Intel	Texas Instruments	Fairchild	AMD	SIGNE
MOS	256 x 8 = 2048			μPD454D①	HN351702A⑦	MB8503 MB8513	M5L1702⑦		1602A 1702A ⑦			AM1702A⑦	1702A ⑦
	512 x 4 = 2048		TMM121C TMM121C-1										
	512 x 8 = 4096								2704 ⑧				
	1024 x 8 = 8192	MSM3758⑧	TMM322C⑧	μPD458D①	HN462708③	MB8518①	M5L2708①		2708 ⑧ 2758 ⑨	TMS2708③	F2708 ⑧	AM2708 ①	2708 ⑧
	2048 x 8 = 16384		TMM323C⑨	μPD2716D②	HN462716③	MB8516③	M5L2716③		2716 ⑨	TMS2716③ TMS2516③			
	4096 x 8 = 32768								2732	TMS2532			
CMOS	512 x 8 = 4096							1M6654④					
	1024 x 4 = 4096							1M6653④					
	1024 x 8 = 8192						M58460 S						
Compound MOS									8755				

## Bipolar Type

Element	Bit configuration, capacity (words x bits = capacity)	Maker name													
		Nihon Denki	Hitachi	Fujitsu	Mitsubishi	Intersil	Intel	Texas Instruments	Harris	Fairchild	Raytheon	MMI	AMD	SIGNE	
Bipolar	32 x 8 = 256			MB7051 MB7056	M54730	1M5600 1M5610		SN74188A SN74S188 SN74S288	HM7602 HM7603	HM76LS03		6330-1 6331-1	AM27S18 AM27S19	82S23 82S123	
	256 x 4 = 1024	μPB403D②		MB7052 MB7057	M54700	1M5603A 1M5623	3601 3621	SN74S287 SN74S387	HM7610A HM7611A	HM7610 HM7611	93417 93427	29662 29663 29660 29661	6300-1 6301-1	AM27S20 AM27S21	82S126 82S129
	256 x 8 = 2048							SN74S470 SN74S471	HM7625R  HM7629		29600 29601	6308-1 6309-1 6335-1 6336-1 63135-1		82S114	
	512 x 4 = 2048			MB7053 MB7058		1M5604 1M5624	3602 3622		HM7620 HM7621	HM7620A HM7621A	93436 93446	29612 29613	6305-1 6306-1	AM27S12 AM27S13	82S130 82S131
	512 x 8 = 4096	μPB405D μPB425D				1M5605 1M5625	3604A 3624A	SN74S472 SN74S473 SN74S474 SN74S475	HM7640 HM7641 HM7640AR HM7647R HM7648 HM7649	H M7640A HM7641A HM7641AR	93438 93448	6341-1 6340-1 6348-1 6349-1	AM27S15  AM27S26 AM27S27	82S115 82S140 82S141	
	1024 x 4 = 4096	μPB406D μPB426D		MB7054 MB7059		1M5606 1M5626	3605A 3625A		HM7642 HM7643 HM7644 HM7642P HM7680 HM7680P HM7680R HM7680RP	HM7642A HM7643A HM7644A HM7643P	93452 93453	6350-1 6351-1 6352-1 6353-1	AM27S32 AM27S33	82S136 82S137	
	1024 x 8 = 8192	μPB417D μPB427D		MB7055 MB7060			3608A 3628A		HM7680 HM7680P HM7680R HM7680RP  HM7608 HM7683	HM7681 HM7681P HM7681R HM7681RP	93450 93451	6380-1 6381-1 6384-1 6385-1 6386-1 6387-1 63133-1		82S180 82S181  82S2708	
	2048 x 4 = 8192								HM7684 HM7684P HM7686 HM7686P HM7686R HM7686RP	HM7685 HM7685P HM7687 HM7687P HM7687R HM7687RP				82S184 82S185	
	2048 x 8 = 16384						3636		HM7616 HM76160 HM76161						82S190 82S191

Elements annotated with the same figures in circles can be used with the same performance boards.



# PROM FORMATTER COMMANDS

## —File Input/Output Commands—

### Y (Yank file) Command

Reads the object (OBJ) file specified by the file name into the free area.

\* YCHARAGEN **[CR]**

Reads in CHARAGEN.OBJ

RAM from? 8000 to 87FF

Specifies read-in from address 8000

(read up to address 87FF)

- File name can be specified by entering a Y (Yank file command) when "\*" appears to indicate that command entry is awaited.
- Specify the starting address of the file to be read in as a 4-digit hexadecimal number. (Reading will start at the address specified regardless of the actual data address of the object file.)
- The last address read is displayed when file read-in is completed.

**Caution:** The address specified for read-in must be in the free area.

### S (Save file) Command

Writes the specified program (or data) in the free area onto a disk.

\* STEST# 2 **[CR]**

Output program (data) to TEST# 2.OBJ

RAM from? 8400 to? 87E7

Output program (data) from address 8400 to 87E7

exec? 1300 data? 1300

Execute address 1300, data address 1300

- Another file name can be specified by entering an S (Save file) command when "\*" appears to indicate that command entry is awaited.
- The addresses of the memory block in the free area which is to be output are specified with 4-digit hexadecimal numbers.
- The execute address and data address of the object (OBJ) file created are specified with 4-digit hexadecimal numbers. The data address is the address to which the program (data) is to be reloaded into memory by a later RUN or LOAD command. The execute address is the address from which a program reloaded into memory is to be executed. Specify 0000 when either of these addresses is not necessary.

## CY (Yank disk) Command

This command loads data in units of 256 bytes from the specified sector(s) of the specified track on the floppy disk in the specified drive into RAM.

```
* CY CR  
  drive? 1  
  track, sect? 0301  
  byte size? 0100  adrs? 7000
```

- Enter the CY command when "\*" appears to indicate that command entry is awaited.
- Specify the number of disk drive containing the floppy disk storing the data to be loaded.
- Enter the track number and the first of the sector numbers in which the data to be loaded is stored as 4 continuous hexadecimal digits.
- Enter the 4 hexadecimal digits which indicate the number of 256 byte units of data, then enter the starting address (4 hexadecimal digits) of the RAM area into which the data is to be loaded.
- The 4-digit hexadecimal number which indicates the amount of data is constructed as shown below.

XX XX

— No numbers other than 0 should be entered in these two places (otherwise, the number of data units specified in first two places will be affected).

— Indicate the number of 256-byte units of data to be loaded.

Ex.) 512 bytes of data are loaded when 0200 is entered (0101 is also interpreted as 0200).

## CS (Save disk) Command

This command saves data in 256-byte units from RAM memory in the specified sector(s) of the specified track of the floppy disk in the specified disk drive.

```
* CS CR  
  drive? 2  
  track, sect? 3002  
  byte size? 0100  adrs? 7000
```

- Enter the CS command when "\*" appears to indicate that command entry is awaited.
- Specify the number of the disk drive containing the floppy disk on which the data is to be saved.
- Enter the track number and the first of the sector numbers in which the data is to be saved as a 4-digit hexadecimal number.
- Enter the 4-digit hexadecimal number which indicates the number of 256 byte units of data, then enter the starting address (4 hexadecimal digits) of the RAM area from which the data is to be saved.
- The 4-digit hexadecimal number which indicates the amount of data is constructed in the same manner as for the CY command.

For example, 0101 is interpreted as 0200.

- The track number must be 3 or greater. Great care must be taken not to destroy existing data on the floppy disk.

## —Formatting Commands—

### P (Punch) Command

Punches data in the free area in the specified format.

* P <input type="text" value="CR"/>	Punch command
filename? CHARAGEN <input type="text" value="CR"/>	File name assigned to the paper tape to be punched.
format? C <input type="text" value="CR"/>	Format C
RAM from? 8000 to? 87FF	Addresses 8000 to 87FF in the free area
PROM address? 0000	PROM write address 0000

- Enter the P (Punch) command when "\*" appears to indicate that command entry is awaited.
- Next, the file name is specified. This is not the file name which is included on the disk but the name which is to be punched at the beginning of the tape. Refer to the explanations of the various formats for details. When no file name is needed, enter only .
- Next, specify the conversion format (A~H) and enter .
- Specify the starting and ending addresses of the memory block in the free area which is to be output with 4-digit hexadecimal numbers.
- Finally, specify the PROM write address. (This step may not be required, depending on the format.)

The P command described above outputs formatted data to a PTP device. (More precisely, \$PTP/LF is used as the output device.)

The PROM FORMATTER can also output converted format data to devices other than PTP (including user I/O and disk).

(Ex. 1)	*P\$USR1 <input type="text" value="CR"/>	Outputs to user I/O
(Ex. 2)	*PXYZ <input type="text" value="CR"/>	Outputs file name XYZ.ASC to the diskette.
(Ex. 3)	*P\$PTP/PE/LF <input type="text" value="CR"/>	Adds even parity to PTP, affixes <input type="text" value="LF"/> after <input type="text" value="CR"/> and outputs the file.

As an application, data may be sent directly to the PROM writer by creating hardware and user routines for its online interface.

### R (Read) Command

This command reads in data formatted in the BNPF, HEXADECIMAL or other format from a paper tape reader.

* R <input type="text" value="CR"/>	Read command
format? C <input type="text" value="CR"/>	Format C
RAM from? 8000 to 83FF	Addresses in the free area into which data is to be read.
filename PROM#2	



- Enter the R (Read) command when "\*" appears to indicate that command entry is awaited.
- Next, specify the format of the data to be read.
- Finally, specify the starting address of the free area into which the data is to be read with a 4-digit hexadecimal number.
- The last data address and the file name are displayed after the read is completed and entry of the next command is awaited.
- With this PROM writer format, it may not be possible to read tapes punched using other programs because of the need to maintain a certain minimum degree of redundancy.

The R command described above reads in formatted data from a PTR device, (More precisely, \$PTR is used as the input device.)

The PROM FORMATTER can also read in converted format data from devices other than PTR (including user I/O and disk).

(Ex. 1) \*R\$USR2

Inputs from user I/O

(Ex. 2) \*RXYZ

Inputs from XYZ.ASC on a disk.

(Ex. 3) \*R\$PTR/PE

Inputs data with even parity affixed from PTR.

## —Other Commands—

### M (Memory dump/modify) Command

This command is used to display and modify the contents of the free area.

* M <input type="text"/>	M command															
RAM from? 7000 to? 7014	Area to be displayed															
7000 ED 73 C8 5F 01 C6 5F 09	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
7008 60 22 D8 CD 3E 28 CA 27	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
7010 28 22 DE 26 CD	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

- Enter the M (Memory dump/modify) command when "\*" appears to indicate that command entry is awaited.
- Next, specify the starting and ending addresses in the free area of the data to be displayed with 4-digit hexadecimal numbers.
- The PROM formatter, in the 40 (80) characters per line mode, divides data in the specified addresses into 8-byte segments and displays the address (4 hexadecimal digits), the 8 (16) bytes of data (as groups of 2 hexadecimal digits) and the 8 (16) corresponding ASCII characters in that order.
- However, when the corresponding ASCII character cannot be displayed, a "." is displayed in its place. Further, data is printed in 16 byte segments when the printer is used with the "#" command.
- Execution of the M command can be suspended or resumed by pressing . A switch can be made to the command entry mode by pressing .
- If no change is required in data displayed using the M command, just press . When a change is required, move the cursor to the position where the change is to be made and press  after entering the 2 new hexadecimal digits. (The change is made when  is pressed.) After data modification is completed, move the cursor to an empty line and press  to return to the command wait state.

- Data can also be changed using the cursor when display is halted with **[SPACE]**. In this case, display is resumed when the cursor is moved to an empty line and **[CR]** is pressed.

**Caution:** Data is only printed when the printer is used with the " # " command; modification of data is not possible in this case.

## V (Verify) Command

Reads data formatted in BNPF, HEXADECIMAL and so forth from the paper tape reader and compares it with the contents of the RAM free area.

* V <b>[CR]</b>	Verify command
format? C <b>[CR]</b>	Format C
RAM from? 8000 to 8615	The start and end addresses of the area containing
filename ABC	the data to be compared.
Verify OK.	

- Enter the V (Verify) command when " \*" appears to indicate that command entry is awaited.
- Specify the format of data to be read.
- Specify the start address (4-digit hexadecimal) of the area containing the data to be compared.
- The end address of the data read is displayed and "Verify OK." is displayed when the data read matches the data compared. If not, the end address is not displayed and "Verify error." is displayed.

## \ (DOS) Command

This command invokes the specified built-in DOS command. Command entry is awaited after execution of the DOS command.

\* \ DIR **[CR]**

- Enter the \ command when " \*" appears to indicate that command entry is awaited.
- Next, specify the built-in DOS command and press the **[CR]** key.
- The PROM formatter executes the built-in DOS command, then awaits entry of the next PROM formatter command.
- The XFER and EXEC commands cannot be executed. The RUN command cannot be executed if the program executed by the RUN command is too long.

## # (Change printer mode) Command

This command starts and stops output to the printer. Printer output is OFF when the PROM formatter is activated, and is changed from ON to OFF to ON each time the " # " command is executed.

When printer output is ON, data is printed almost as it appears on the display screen.

## & (Clear) Command

Buries the entire free area in hexadecimal code FFH.

## ? (Disp free area) Command

Displays the free area.

## ! (Return) Command

Terminates the PROM formatter and returns to Floppy DOS.

## —Format Commands—

Format commands are commands entered when "format?" is displayed during execution of the P, R or V commands. Selecting one of these commands during execution of the P command determines whether data is to be punched in BNPF, HEXADECEMAL or other format. Failure to specify the correct format command during execution of the R command will result in failure to correctly read the program into the free area.

### A Command

- Used to specify the Britronics BNPF format. The control character "B" may not be used when the file name is specified.

### B Command

- Used to specify the Britronics HEXADECEMAL format.

### C Command

- Used to specify the Britronics BINARY format. Numerals and the codes (; < = > ?) may not be used when the file name is specified.
- The message "PROM address?" is displayed during execution of the P command to request specification of the PROM loading address; specify it as a 4-digit number.
- Check sums are written following the data (with the P command).
- Data from the address specification to the check sums constitutes one block; if data is to be loaded into an address which has been skipped, the operation must be divided into two or more parts. This also applies when two or more blocks are read in with the R command.

### D Command

- This command is used to specify the Intel BNPF format. The character "B" cannot be used in the file name.

### E Command

- This command is used to specify the Takeda Riken BNPF format. The character "B" may be used in the file name.
- A file is a block which begins with "\$" and ends with ")".
- The message "PROM address?" is displayed during execution of the P command to request specification of the PROM loading address; specify it as a 4-digit number.
- If two or more blocks are to be read out or written in, the operation must be divided into two or more parts.

## F Command

- This command is used to specify the Takeda Riken B10F format. The character "B" may be used in the file name.
- A file is a block which begins with " \$ " and ends with " ) ".
- The message "PROM address?" is displayed during execution of the P command to request specification of the PROM loading address; specify it as a 4-digit number.
- If two or more blocks are to be read out or written in, the operation must be divided into two or more parts.

## G Command

- This command is used to specify the Takeda Riken HEXADECIMAL format.
- A file is block which begins with " \$ " and ends with " ) ".
- The message "PROM address?" is displayed during execution of the P command to request specification of the PROM loading address; specify it as a 4-digit number.
- If two or more blocks are to be read out or written in, the operation must be divided into two or more parts.

## H Command

- This command is used to specify the Minato Electronics HEXADECIMAL format.
- The start-of-data symbol " [ " may not be used in the file name.
- The message "PROM address?" is displayed during execution of the R command to request specification of the PROM loading address; specify it as a 4-digit number.
- Denote the end of data with the symbol " ] ".



# PROM FORMATTER (SB-7501) COMMANDS & MESSAGES

COMMAND		OPERATION
File Input/ Output commands	Y (Yank)	Loads a program (data) from the disk into the free area.
	S (Save)	Saves the program (data) in the free area on disk.
	CY (Yank disk)	Loads data in 256-byte units from the specified sector(s) of the specified track on the disk into RAM.
	CS (Save disk)	Saves data in 256-byte units from RAM memory in the specified sector(s) of the specified track of the disk.
Format commands	P (Punch)	Punches the specified contents of the free area in the specified format.
	R (Read)	Reads in a paper tape punched in the format specified.
Other commands	M (Memory)	Displays and modifies data in the free area.
	V (Verify)	Reads data from the paper tape reader and compares it with the contents of the RAM free area.
	\ (DOS)	Executes the specified built-in DOS command.
	#	Switches the list mode for listing on a printer.
	& (Clear)	Buries all data in the free area in hexadecimal code FFH.
	?	Displays the starting and ending addresses of the free area.
	! (Return)	Returns control to Floppy DOS.

Error message	Error content	Related command
memory protection	An address outside of the free area was specified.	Y, S, P, R, M, V
il command	The command was not entered correctly.	
il data	The format specified does not match the format read.	R, V
check sum	Check sum error.	R, V
\$ LPT : not ready	The printer is not ready.	#
\$ PTP : not ready	The paper tape punch is not ready.	P
\$ PTR : not ready	The paper tape reader is not ready.	R, V

See the "System Error Messages" in System Command for other error messages.

## Caution:

Entry of characters other than S, Y, CS, CY, P, R, M, V, \, &, #, ? or ! will cause a return to the command wait state after the command table is displayed.

If a character other than A~H is input while "format?" is displayed and format entry awaited, the format table will be displayed, after which the format entry wait state will be reentered. A return can be made to the command wait state at this time by pressing **BREAK**.




# EXAMPLE OF PLOTTER CONTROL APPLICATION

Use of the Floppy DOS editor, assembler and BASIC compiler allows the familiar BASIC language to be used to write main programs without loss in processing speed, as long as control programs are created for control of the various devices. Another benefit is that commands developed by the user can be used as BASIC commands.

## —Interface Card—

Universal interface card MZ-80IO2 is used for the interface between the MZ-80B computer and the MILOT WX4671 plotter.

The connection conditions are as shown in Figure 1.



a) Connection conditions for all input/output terminals b) Address switch settings c) Data line termination conditions

Fig. 1 Connection conditions

SN7404 is included as the data driver for the universal interface card, but ICs 16 and 17 only are changed to SN7406. All data line and status input terminations are made as shown in Figure 1-c). A 1.5 m cable can be used for this purpose.

See the universal interface card instructions for details.

## —Plotter Control Program—

This section may skip if you are not interested in assembly subroutines.

### 1. Conditions for linkage with a BASIC program

Conditions for linkage with a BASIC program

- Command names must be externally declared with the ENT statement .....SIZE : ENT
- The number of parameters must be specified ..... DEFB 1 (1 parameter)
- The parameter type must be specified. .... DEFB 0 (real number)
- Buffers must be specified for parameters. .... SE : DEFS 2 (2 bytes reserved)
- The RET instruction must be included at the end of all control routines.

The above are the linkage conditions; the processing program is written between items (d) and (e).

## 2. Linkage conditions when an error occurs

- (a) A subroutine is used from Floppy DOS library RELO.LIB ..... CALL BEERR
- (b) The error number is written. .... DEFB 80
- (c) The error message is written. .... DEFM 'PLOTTER ERROR'
- (d) The terminator is written. .... DEFB 0DH

This causes \* ER 80:PLOTTER ERROR to be output on the display screen when a plotter error occurs.

## 3. Use of external subroutines

This control program uses 4 routines out of the subroutines included in Floppy DOS library RELO.LIB. One of these is BEERR, which was shown above; the remaining three are as follows;

- (a) .. INTO

16 bit binary data is set in the HL register with a sign attached when an address with a parameter is loaded in the HL register and called. All registers except the AF register are protected in the event of an overflow if the carry flag is set.

- (b) CASC'

The unsigned 16-bit binary data from the HL register is converted to ASCII code and stored in the address indicated in the DE register, then 0DH is set.

- (c) . MOVE'

When the parameter contains a type 1 string and an address with data is loaded in the HL register and called, a type 2 string is set in the address indicated by the DE register and 0DH is set.

See the "LIBRARY/PACKAGE" instructions for details on all subroutines.

## 4. Plotter control codes

All data for the MILOT WX4671 currently used is in 7-bit ASCII code. Input statuses include the BUSY signal and the ERROR signal. Data output is possible when the BUSY signal goes low, and the data is taken in on the plotter side when the STROBE signal is output.

", " (that is, 2CH) is used as the data delimiter and 03H~0DH are valid as data terminators. However, only 0AH will be accepted when an error occurs; an error condition is not cleared by any data terminator other than 0AH.

At the port on the MZ-80 side, 0EH is used for the status (that is, as the input for the BUSY and ERROR signals) and 0FH is used for the data and STROBE signal output.

## 5. Program outline

Linkage conditions for a BASIC program have already been indicated; however, string type becomes applicable in the parameter type specification with the 80H. Moreover, parameter types and parameter buffers must be added depending on the number of parameters; the steps described in subparagraphs (c) and (d) of that section are not required if the number of parameters is zero. See routines CTYPE, SIZE, PLOT, HOME and so forth of the assembly listing for this.

This illustrated using the PLOT routine as a representative example. The flowchart is as shown in Figure 2 (pages 4 and 5).

### (a) Data output

Although subroutines COUT, PLOT1 and DOUT are used, DOUT is the one which actually outputs the data. With DOUT, the data set in the accumulator is output to the plotter with the STROBE signal if the BUSY signal of the plotter is LOW. If BUSY is HIGH the routine repeats a loop.

With COUT and PLOT1, the data at the address indicated in the HL register is loaded in the accumulator and then DOUT is executed; this is repeated until 0DH is output. After 0DH is output, a check is made for plotter errors and a jump is made to the error routine if any are found. Note that continuation of program execution is possible if ON ERROR processing is provided on the BASIC side.

### (b) Data conversion routine


As was indicated previously, all data must be converted into ASCII code since the plotter will not accept data in any other form.

Subroutine BTOA uses the RELO.LIB routine in Floppy DOS to convert data to ASCII code. This is as shown in the flowchart in Figure 2-a) and paragraph 3, "Use of external subroutines"; however, checks are also made for positive, negative and overflow data.

### (c) PLOT x, y routine

As is shown in the flowchart, the two parameters x and y are specified following the external declaration. The parameter type is real number and two bytes are set in the parameter buffer for both x and y.


The pre-conversion data address, the starting address of the buffer for storage of the data after conversion and the maximum value of x are loaded in registers HL, DE and BC, respectively, then BTOA is called and the data is checked and converted to ASCII code. Afterwards, the data delimiter for the plotter ", " is loaded and the process is repeated for y. The starting address of the data converted into ASCII code is loaded into the HL register, the 44H ("D") command (which draws a line on the plotter) is loaded and COUT is called. With COUT, the contents of the address indicated in the HL register are output to the plotter following the command.



a) ASCII conversion subroutine

Fig. 2 PLOT routine

Table 1. Plotter control commands



b) Data output subroutine

Fig. 2 PLOT routine



## —Command Table—

Table 1. Plotter control commands

Command name	Function
<b>PLOT x, y</b>	Draws a straight line from the current position of the pen to the coordinates x, y; x = 0 ~ 3600, y = 0 ~ 2540 are the possible range (other values will result in an error).
<b>IPLLOT <math>\Delta x, \Delta y</math></b>	Draws a straight line from the current position of the pen for the values of $\pm \Delta x, \pm \Delta y$ only.
<b>MOVE x, y</b>	Lifts the pen and moves it to the position indicated by coordinates x and y. x = 0 ~ 3600, y = 0 ~ 2540 are the possible range (other values will result in an error).
<b>IMOVE <math>\Delta x, \Delta y</math></b>	Lifts the pen and moves it by an amount indicated by $\pm \Delta x, \pm \Delta y$ .
<b>XAXIS x, n</b>	Draws a scale with n divisions on the X axis at intervals indicated by x.
<b>YAXIS x, n</b>	Draws a scale with n divisions on the Y axis at intervals indicated by y.
<b>CTYPE A\$</b>	Prints the character string indicated by A\$.
<b>SIZE n</b>	Specifies that characters are to be written in the size indicated by n; n = 0 ~ 15
<b>CSIZE</b>	Specifies that characters are to be written in the size initially set for the plotter. (n = 4 is output automatically.)
<b>DOT x</b>	Draws a dotted line over the interval specified by x. (x $\leq$ 127)
<b>DOTM</b>	Draws a line of dots spaced at intervals of 3 mm.
<b>DOT0</b>	Clears DOT x or DOTM and returns to a straight line.
<b>PUP</b>	Pen up (same function as IMOVE0, 0)
<b>PDOWN</b>	Pen down (same function as IPLOT0,0)
<b>ANGL n</b>	Rotates characters by the angle (in the counterclockwise direction) specified by n. n = 0 ~ 3 n = 0 ... 0°      n = 1 ... 90°      n = 2 ... 180°      n = 3 ... 270°
<b>MARK n</b>	Writes the mark specified by n. n = 1 ~ 6 n = 1 ... ·      n = 2 ... ◇      n = 3 ... □      n = 4 ... ▲      n = 5 ... ✕      n = 6 ... ⊕
<b>HOME</b>	Moves the pen to the x, y coordinates it was at when the power was turned on, clears the error lamp and clears plotter error.
<b>ERCLR</b>	Clears plotter errors when they occur; the error lamp is not cleared, however.
<b>(Note)</b>	Values indicated by x and y are specified as integral multiples of 0.1 mm; for example, PLOT 100, 2000 results in a line being drawn to x = 10 mm and y = 200 mm.

## —Outline of the BASIC Program—




Fig. 3 Flowchart of the BASIC program

As is indicated in the flowchart at left, the program consists of 10 subroutines.

At ①, the EXTERNAL statement is used for linking the program with the plotter control program commands. Although it is not necessary to use line numbers with statements other than GOTO and GOSUB, they are used in other locations to make the program easier to understand.

At ②, the title of Floppy DOS is drawn from line number 110 to 910. This routine uses the MOVE, IMOVE, PLOT and IPLOT commands.

At ③, a diamond pattern is drawn from line number 920 to 1050. MOVE X, Y is used to return the pen to the starting point, while IPLOT A, B is used to draw the pattern.

At ④, "3D-GRAPH" specified by A\$ is written at 90° angles with ANGL 1 and CTYPE A\$ from line number 1090 to 1140.

At ⑤, repetitions of attenuated SIN(X) and a 3-dimensional graph are drawn from line number 1190 to 1910. The 3-dimensional graph is drawn in dots using the PUP and PDOWN commands.

Try changing the program from line number 1500 to 1510 as shown below to draw the graph with solid lines.

```

1500 IF (A - 2) > T THEN 1520
1502 T = A
1504 IF S = 0 THEN MOVE DX, DY : GOTO 1508
1506 PLOT DX, DY
1508 PDOWN : S = 1
1510 RETURN
1520 MOVE DX, DY : T = A : S = 0 : GOTO 1510
  
```

With this program, S indicates the pen status; S = 0 raises the pen while S = 1 lowers it.

At ⑥, scales are drawn on the X and Y axes with the XAXIS and YAXIS commands and marks are drawn on the graph with the MARK command; this processing is performed from line 1990 to line 2190. The dotted line is drawn with the DOTM command, and the DOT0 command is used to return to a solid line. The curve is a drawing of  $\sin(X)/X$ . Refer to the command table for these commands.

At ⑦, the SIZE command is used from line number 2390 to 2460 to write the word SHARP in characters of varying sizes. Afterwards, the CSIZE command is used to return to standard size.

At ⑧, representative characters of standard size are drawn from line number 2790 to 2820.

At ⑨, the HOME, DOT and DOT0 commands are used from line number 3000 to 5010 to draw the surrounding outline by changing between solid lines and dotted lines of varying pitch.

At ⑩, pen up and pen down are tested from line number 5100 to END.

If the program is written so that the HOME command can be executed if an error occurs with the plotter, the error can be cleared, the error lamp extinguished and the pen returned to the starting position. If the ERCLR command is used (it is not in this program), the error can be cleared without moving the pen; however, in this case the error lamp is not extinguished.

## —Conclusion—

As has been shown above, user-written programs can be easily linked with BASIC. By observing the conditions for linkage, it is possible to connect many devices other than the plotter. When a main program is created using the assembler, it may be necessary to output a picture on the display screen. The BASIC compiler and Floppy DOS are very useful for this purpose. Further, the processing is the same as with machine language. The photograph on page 9 shows the result of execution of this program.





Fig. 3 Flowchart of the BASIC program





## —References—

1. Watanabe Manufacturing Co., MILOT WX4671 Instruction Manual
2. Sharp Corp., Universal Interface Card Instruction Manual

# —Sample Program (Plotter Control Routines)—

\*\* Z80 ASSEMBLER SB-7201 <PLOTTER> PAGE 01

07/09/81

```

01 0000      ;
02 0000      ;
03 0000      ; MZ-80B Plotter control package.
04 0000      ; Plotter WX-4671 & universal I/O.
05 0000      ;
06 0000      ; Copyright 1981 by SHARP Corp.
07 0000      ;
08 0000      ;
09 0000      ; BASIC SUBROUTIN LINK
10 0000      ;
11 0000      ;
12 0000      ; CALL ..INT0
13 0000      ; WITHOUT AF KEEP
14 0000      ; 16BIT BINARY TO HL
15 0000      ;
16 0000      ; CALL CASC'
17 0000      ; WITHOUT AF KEEP
18 0000      ; HL(16BIT BINARY) TO DE ADDRESS
19 0000      ; (DE)=ASCII END=0DH
20 0000      ;
21 0000      ; CALL BEERR
22 0000      ; ERROR MSG DSP-OUT
23 0000      ;
24 0000      ; CALL .MOVE'
25 0000      ; CHR TYPE PARAMETER TO ASCIICODE(HL TO DE)
26 0000      ;
27 0000      ;
28 0000      ; PORT
29 0000      ;
30 0000 P     PLTS: EQU 0EH          ;PLOTTER STATUS READ
31 0000 P     PLTD: EQU 0FH          ;PLOTTER DATA OUT
32 0000      ;
33 0000      ; MOVE X,Y(PEN UP)
34 0000      ;
35 0000      ; MBUFF: DEFS +16
36 0010      ;
37 0010      ; MOVE: ENT
38 0010 02    DEFB 2                ;NO OF PARAMETER
39 0011 00    DEFB 0                ;REAL NO.
40 0012      ;
41 0014 00    DEFS +2               ;REAL NO.
42 0015      ;
43 0017      ;
44 0017 2A1200 LD HL,(MX)
45 001A 110000 LD DE,MBUFF
46 001D D5     PUSH DE
47 001E 01110E LD BC,0E11H          ;3600
48 0021 CD5202 CALL BTOA
49 0024 CD8302 CALL INS2C
50 0027 2A1500 LD HL,(MY)
51 002A 01ED09 LD BC,09EDH          ;2540
52 002D CD5202 CALL BTOA
53 0030 E1     POP HL
54 0031 3E4D    LD A,4DH             ;'M' MOVE CMD
55 0033 C34201 JP COUT
56 0036      ;
57 0036      ; INCREASE MOVE(PEN UP)DX,DY
58 0036      ;
59 0036      ; IMBUFF: DEFS +16
60 0046      ;

```

```

01 0046      IMOVE: ENT      LD      HL,(IMX)
02 0046 02      DEFB 2      ;NO OF PARAMETER
03 0047 00      DEFB 0      ;REAL
04 0048      IMX:  DEFS +2
05 004A 00      DEFB 0      ;REAL
06 004B      IMY:  DEFS +2
07 004D      ;
08 004D 2A4800      LD      HL,(IMX)
09 0050 113600      LD      DE,IMBUFF
10 0053 D5      PUSH DE
11 0054 01110E      LD      BC,0E11H      ;3600
12 0057 CD6202      CALL  NSBTOA
13 005A CD8302      CALL  INS2C
14 005D 2A4B00      LD      HL,(IMY)
15 0060 01ED09      LD      BC,09EDH      ;2540
16 0063 CD6202      CALL  NSBTOA
17 0066 E1      POP      HL
18 0067 3E52      LD      A,52H      ;'R' RELATIVE MOVE CMD
19 0069 C34201      JP      COUT
20 006C      ;
21 006C      ; X-AXIS
22 006C      ;
23 006C      QRXBUF: DEFS +16
24 007C      ;
25 007C      XAXIS: ENT      LD      HL,(QX)
26 007C 02      DEFB 2      ;NO OF PARAMETER
27 007D 00      DEFB 0      ;REAL
28 007E      QX:  DEFS +2
29 0080 00      DEFB 0      ;REAL
30 0081      RX:  DEFS +2
31 0083      ;
32 0083 2A7E00      LD      HL,(QX)
33 0086 116C00      LD      DE,QRXBUF
34 0089 D5      PUSH DE
35 008A 01110E      LD      BC,0E11H      ;3600
36 008D CD5202      CALL  BTOA
37 0090 CD8302      CALL  INS2C
38 0093 2A8100      LD      HL,(RX)
39 0096 01110E      LD      BC,0E11H      ;3600
40 0099 CD5202      CALL  BTOA
41 009C 3E31      LD      A,31H      ;'1'
42 009E 1832      JR      AXOUT
43 00A0      ;
44 00A0      ; Y-AXIS
45 00A0      ;
46 00A0      QRYBUF: DEFS +16
47 00B0      ;
48 00B0      YAXIS: ENT      LD      HL,(QY)
49 00B0 02      DEFB 2      ;NO OF PARAMETER
50 00B1 00      DEFB 0      ;REAL
51 00B2      QY:  DEFS +2
52 00B4 00      DEFB 0      ;REAL
53 00B5      RY:  DEFS +2
54 00B7      ;
55 00B7 2AB200      LD      HL,(QY)
56 00BA 11A000      LD      DE,QRYBUF
57 00BD D5      PUSH DE
58 00BE 01ED09      LD      BC,09EDH      ;2540
59 00C1 CD5202      CALL  BTOA
60 00C4 CD8302      CALL  INS2C

```

```

01 00C7 2AB500          LD    HL,(RY)
02 00CA 01ED09          LD    BC,09EDH      ;2540
03 00CD CD5202          CALL  BTOA
04 00D0 3E30           LD    A,30H      ;'0'
05 00D2 CD2302          AXOUT: CALL  AXIS
06 00D5 E1             POP    HL
07 00D6 186D           JR     PLOT1
08 00D8                ;
09 00D8                ; INCREASE PLOT X+DX,Y+DY
10 00D8                ;
11 00D8          IPBUFF: DEFS  +16
12 00E8                ;
13 00E8          IPLOT:  ENT
14 00E8 02            DEFB  2            ;NO OF PARAMETER
15 00E9 00            DEFB  0            ;REAL
16 00EA          IPX:  DEFS  +2
17 00EC 00            DEFB  0            ;REAL
18 00ED          IPY:  DEFS  +2
19 00EF                ;
20 00EF 2AEA00          LD    HL,(IPX)
21 00F2 11D800          LD    DE,IPBUFF
22 00F5 D5             PUSH  DE
23 00F6 01110E          LD    BC,0E11H      ;3600
24 00F9 CD6202          CALL  NSBTOA
25 00FC CD8302          CALL  INS2C
26 00FF 2AED00          LD    HL,(IPY)
27 0102 01ED09          LD    BC,09EDH      ;2540
28 0105 CD6202          CALL  NSBTOA
29 0108 E1             POP    HL
30 0109 3E49           LD    A,49H      ;'I' INCREASE CMD
31 010B 1835           JR     COUT
32 010D                ;
33 010D                ; PLOT X,Y
34 010D                ;
35 010D          PTBUFF: DEFS  +16
36 011D                ;
37 011D                ;
38 011D          PLOT:  ENT
39 011D 02            DEFB  2            ;NO OF PARAMETER
40 011E 00            DEFB  0            ;REAL
41 011F          PX:   DEFS  +2
42 0121 00            DEFB  0            ;REAL
43 0122          PY:   DEFS  +2
44 0124                ;
45 0124 2A1F01          LD    HL,(PX)
46 0127 110D01          LD    DE,PTBUFF
47 012A D5             PUSH  DE
48 012B 01110E          LD    BC,0E11H      ;3600
49 012E CD5202          CALL  BTOA
50 0131 CD8302          CALL  INS2C
51 0134 2A2201          LD    HL,(PY)
52 0137 01ED09          LD    BC,09EDH      ;2540
53 013A CD5202          CALL  BTOA
54 013D E1             POP    HL
55 013E 3E44           LD    A,44H      ;'D' DRAW CMD
56 0140 1800           JR     COUT
57 0142                ;
58 0142                ; ASCII CODE OUT SUB
59 0142                ;
60 0142 CD2F02          COUT: CALL  DOUT

```

```

01 0145 7E          PLOT1: LD  A,(HL)
02 0146 CD2F02      CALL DOUT
03 0149 E67F        AND  7FH
04 014B FE0D        CP   0DH
05 014D 2803        JR   Z,CKER
06 014F 23          INC  HL
07 0150 18F3        JR   PLOT1
08 0152            ;
09 0152            ; ERROR CHECK
10 0152            ;
11 0152 CDCE02      CKER:  CALL DLY
12 0155 DB0E        IN   A,(PLTS)
13 0157 E602        AND  02H          ;CKER(BIT 1=0?)
14 0159 C0          RET  NZ
15 015A CD0000      E    CKER1: CALL BEERR
16 015D 50          DEFB 50H          ;80
17 015E 504C4F54    DEFM 'PLOTTER ERROR'
18 0162 54455220
19 0166 4552524F
20 016A 52
21 016B 0D          DEFB 0DH
22 016C            ;
23 016C            ; PRINT ASCII
24 016C            ;
25 016C            CTYPE: ENT
26 016C 01          DEFB 1          ;NO OF PARAMETER
27 016D 80          DEFB 80H        ;CHR
28 016E            TP:  DEFS +2
29 0170            ;
30 0170 2A6E01      LD   HL,(TP)
31 0173 CD0000      E    CALL ,MOVE'
32 0176 EB          EX   DE,HL
33 0177 3E50        LD   A,50H      ;'P' PRINT CMD
34 0179 18C7        JR   COUT
35 017B            ;
36 017B            ; SIZE ALPHA
37 017B            ;
38 017B            SBUF: DEFS +5
39 0180            ;
40 0180            SIZE: ENT
41 0180 01          DEFB 1          ;NO OF PARAMETER
42 0181 00          DEFB 0          ;REAL
43 0182            SE:  DEFS +2
44 0184            ;
45 0184 2A8201      LD   HL,(SE)
46 0187 117B01      LD   DE,SBUF
47 018A 011000      LD   BC,0010H   ;15
48 018D CD5202      CALL BTOA
49 0190 EB          EX   DE,HL
50 0191 3E53        LD   A,53H      ;'S' SCALE CMD
51 0193 18AD        JR   COUT
52 0195            ;
53 0195            ; DOT LINE
54 0195            ;
55 0195            DBUF: DEFS +5
56 019A            ;
57 019A            DOT:  ENT
58 019A 01          DEFB 1          ;NO OF PARAMETER
59 019B 00          DEFB 0          ;REAL
60 019C            DT:  DEFS +2

```

```

01 019E      ;
02 019E 2A9C01 LD HL,(DT)
03 01A1 119501 LD DE,DBUF
04 01A4 018000 LD BC,0080H
05 01A7 CD5202 CALL BTOA
06 01AA EB     EX DE,HL
07 01AB 3E42   DOTWR: LD A,42H      ;'B' LINE GAGE CMD
08 01AD CD4201 CALL COUT
09 01B0 21A202 LD HL,DOTMSG
10 01B3 188D   JR COUT
11 01B5      ;
12 01B5      DOTM: ENT
13 01B5 00     DEFB 0      ;NO PARAMETER
14 01B6 219F02 LD HL,DOIMSG
15 01B9 18F0   JR DOTWR
16 01BB      DOT0: ENT
17 01BB 00     DEFB 0      ;NO PARAMETER
18 01BC 219C02 LD HL,LTMSG
19 01BF 180A   JR CNCT
20 01C1      CSIZE: ENT
21 01C1 00     DEFB 0      ;NO PARAMETER
22 01C2 21A502 LD HL,ISMSG
23 01C5 1804   JR CNCT
24 01C7      ;
25 01C7      ; PEN UP
26 01C7      ;
27 01C7      PUP: ENT
28 01C7 00     DEFB 0      ;NO PARAMETER
29 01C8 21A802 LD HL,PUMSG
30 01CB C34501 CNCT: JP PLOT1
31 01CE      ;
32 01CE      ; PEN DOWN
33 01CE      ;
34 01CE      PDOWN: ENT
35 01CE 00     DEFB 0      ;NO PARAMETER
36 01CF 21AD02 LD HL,PDMSG
37 01D2 18F7   JR CNCT
38 01D4      ;
39 01D4      ; ERROR CLEAR
40 01D4      ;
41 01D4      ERCLR: ENT
42 01D4 00     DEFB 0      ;NO PARAMETER
43 01D5 1806   JR LFOUT
44 01D7      ;
45 01D7      ; HOME
46 01D7      ;
47 01D7      HOME: ENT
48 01D7 00     DEFB 0      ;NO PARAMETER
49 01D8 3E48   LD A,48H      ;'H' HOME
50 01DA CD2F02 CALL DOUT
51 01DD 3E0A   LFOUT: LD A,0AH ;ER CLEAR CMD
52 01DF 184E   JR DOUT
53 01E1      ;
54 01E1      ; ROTATE ALPHA
55 01E1      ;
56 01E1      PBUF: DEFS +5
57 01E6      ;
58 01E6      ANGL: ENT
59 01E6 01     DEFB 1      ;NO OF PARAMETER
60 01E7 00     DEFB 0      ;REAL

```

```

01 01E8          AL: DEFS 2
02 01EA          ;
03 01EA 2AE801   LD HL,(AL)
04 01ED 11E101   LD DE,PBUF
05 01F0 010400   LD BC,0004H
06 01F3 CD5202   CALL BTOA
07 01F6 EB       EX DE,HL
08 01F7 3E51     LD A,51H      ;'Q' ROTATE CMD
09 01F9 C34201   JP COUT
10 01FC          ;
11 01FC          ; MARK
12 01FC          ;
13 01FC          MBUF: DEFS +5
14 0201          ;
15 0201          MARK: ENT
16 0201 01       DEFB 1        ;NO OF PARAMETER
17 0202 00       DEFB 0        ;REAL
18 0203          MK: DEFS +2
19 0205          ;
20 0205 2A0302   LD HL,(MK)
21 0208 CD0000   CALL ..INT0
22 020B DA0000   JP C,ER3
23 020E CDB202   CALL CKNEG
24 0211 010700   LD BC,0007H
25 0214 CD8D02   CALL CKCOD0
26 0217 11FC01   LD DE,MBUF
27 021A CD0000   CALL CASC'
28 021D EB       EX DE,HL
29 021E 3E4E     LD A,4EH      ;'N' MARK CND
30 0220 C34201   JP COUT
31 0223          ;
32 0223          ; AXIS SUB
33 0223          ;
34 0223 F5       AXIS: PUSH AF
35 0224 3E58     LD A,58H      ;'X' AXIS CMD
36 0226 CD2F02   CALL DOUT
37 0229 F1       POP AF
38 022A CD2F02   CALL DOUT
39 022D 3E2C     AXIS1: LD A,2CH ;',' DELIMITER
40 022F          ;
41 022F          ;
42 022F          ;
43 022F          ;
44 022F          ; PLOTTER DATA CONTROL
45 022F          ; A=DATA
46 022F          ;
47 022F          ;
48 022F          ;
49 022F F5       DOUT: PUSH AF
50 0230 DB0E     DOUTP: IN A,(PLTS)
51 0232 CB47     BIT 0,A
52 0234 20FA     JR NZ,DOUTP
53 0236 F1       POP AF
54 0237 D30E     OUT (PLTD),A
55 0239 F680     OR 80H
56 023B CDCE02   CALL DLY
57 023E D30E     OUT (PLTD),A
58 0240 F5       PUSH AF
59 0241 DB0E     DOUTQ: IN A,(PLTS)
60 0243 CB47     BIT 0,A

```

```

01 0245 28FA          JR    Z,DOUTQ
02 0247 3EFF          LD    A,FFH
03 0249 3D            DEC    A
04 024A 20FD          JR    NZ,-1
05 024C F1            POP    AF
06 024D E67F          AND    7FH
07 024F D30E          OUT    (PLTD),A
08 0251 C9            RET
09 0252                ;
10 0252                ; BINARY TO ASCII
11 0252                ;
12 0252 CD0000        E    BTOA: CALL ..INT0
13 0255 DA0000        E    JP    C,ER3
14 0258 CDB202        CALL CKNEG
15 025B CD9202        CALL CKCOD
16 025E CD0000        E    CALL CASC'
17 0261 C9            RET
18 0262                ;
19 0262                ;
20 0262 CD0000        E    NSBTOA: CALL ..INT0
21 0265 DA0000        E    JP    C,ER3
22 0268 CD7202        CALL INS2D
23 026B CD9202        CALL CKCOD
24 026E CD0000        E    CALL CASC'
25 0271 C9            RET
26 0272                ;
27 0272                ; IF NEG... INSERT '--'
28 0272                ;
29 0272 7C            INS2D: LD    A,H
30 0273 CB7F          BIT    7,A
31 0275 C8            RET    Z
32 0276 3E2D          LD    A,2DH
33 0278 12            LD    (DE),A
34 0279 13            INC    DE
35 027A 7D            LD    A,L
36 027B 2F            CPL
37 027C 6F            LD    L,A
38 027D 7C            LD    A,H
39 027E 2F            CPL
40 027F 67            LD    H,A
41 0280 23            INC    HL
42 0281 C9            RET
43 0282                ;
44 0282                ; SEEK 0D, INSERT 2C
45 0282                ;
46 0282 13            INC    DE
47 0283 1A            INS2C: LD    A,(DE)
48 0284 FE0D          CP    0DH
49 0286 20FA          JR    NZ,INS2C-1
50 0288 3E2C          LD    A,2CH
51 028A 12            LD    (DE),A
52 028B 13            INC    DE
53 028C C9            RET
54 028D                ;
55 028D                ; CHECK DATA VALUE
56 028D                ;
57 028D 7C            CKCOD0: LD    A,H
58 028E B5            OR    L
59 028F CA0000        E    JP    Z,ER3
60 0292 E5            CKCOD: PUSH HL

```



```

01 0293 B7          OR      A
02 0294 ED42        CKMAX:  SBC  HL,BC
03 0296 F20000      E      JP   P,ER3
04 0299 E1          POP    HL
05 029A B7          OR      A
06 029B C9          RET
07 029C            ;
08 029C            ; LINE MSG
09 029C            ;
10 029C 4C          LTMSG:  DEFB  4CH      ;'L' LINE CMD
11 029D 30          DEFB  30H      ;'0'
12 029E 0D          DEFB  0DH
13 029F            ;
14 029F            ; BETWEEN DOT
15 029F            ;
16 029F 33          DOIMSG: DEFB  33H      ;'3'
17 02A0 30          DEFB  30H      ;'0'
18 02A1 0D          DEFB  0DH
19 02A2            ;
20 02A2            ; DOT MSG
21 02A2            ;
22 02A2 4C          DOTMSG: DEFB  4CH      ;'L' LINE CMD
23 02A3 31          DEFB  31H      ;'1'
24 02A4 0D          DEFB  0DH
25 02A5            ;
26 02A5            ; INITIAL SIZE SET
27 02A5            ;
28 02A5 53          ISMSG:  DEFB  53H      ;'S'
29 02A6 34          DEFB  34H      ;'4'
30 02A7 0D          DEFB  0DH
31 02A8            ;
32 02A8            ; PEN UP MSG
33 02A8            ;
34 02A8 52          PUMSG:  DEFB  52H      ;'R' RELATIVE CMD
35 02A9 30          DEFB  30H      ;'0'
36 02AA 2C          DEFB  2CH      ;'2'
37 02AB 30          DEFB  30H      ;'0'
38 02AC 0D          DEFB  0DH
39 02AD            ;
40 02AD            ; PEN DOWN MSG
41 02AD            ;
42 02AD 49          PDMSG:  DEFB  49H      ;'I' INCREASE CMD
43 02AE 30          DEFB  30H      ;'0'
44 02AF 2C          DEFB  2CH      ;'2'
45 02B0 30          DEFB  30H      ;'0'
46 02B1 0D          DEFB  0DH
47 02B2            ;
48 02B2            ; CHECK DATA SIGN
49 02B2            ;
50 02B2 7C          CKNEG:  LD   A,H
51 02B3 CB7F        BIT   7,A
52 02B5 C8          RET     Z
53 02B6 CD0000      E      CKER2: CALL BEERR
54 02B9 51          DEFB  51H      ;81
55 02BA 554E464F    DEFM  'UNFORMAT DATA ERROR'
56 02BE 524D4154
57 02C2 20444154
58 02C6 41204552
59 02CA 524F52
60 02CD 0D          DEFB  0DH

```

```

01 02CE      ;
02 02CE C5   DLY:  PUSH BC
03 02CF F5   PUSH AF
04 02D0 060A LD  B,10
05 02D2 AF   DLY2: XOR  A
06 02D3 3D   DEC  A
07 02D4 20FD JR   NZ,-1
08 02D6 10FA DJNZ DLY2
09 02D8 F1   POP  AF
10 02D9 C1   POP  BC
11 02DA C9   RET
12 02DB      END
    
```

AL	01E8	ANGL	01E6	AXIS	0223	AXIS1	022D	AXOUT	00D2
BTOA	0252	CKCOD	0292	CKCOD0	028D	CKER	0152	CKER1	015A
CKER2	02B6	CKMAX	0294	CKNEG	02B2	CNCT	01CB	COUT	0142
CSIZE	01C1	CTYPE	016C	DBUF	0195	DLY	02CE	DLY2	02D2
DOIMSG	029F	DOM0	01BB	DOT	019A	DOTM	01B5	DOTMSG	02A2
DOTWR	01AB	DOUT	022F	DOUTP	0230	DOUTQ	0241	DT	019C
ERCLR	01D4	HOME	01D7	IMBUFF	0036	IMOVE	0046	IMX	0048
IMY	004B	INS2C	0283	INS2D	0272	IPBUFF	00D8	IPLOT	00E8
IPX	00EA	IPY	00ED	ISMSG	02A5	LFOUT	01DD	LTMSG	029C
MARK	0201	MBUF	01FC	MBUFF	0000	MK	0203	MOVE	0010
MX	0012	MY	0015	NSBTOA	0262	PBUF	01E1	PDMSG	02AD
PDOWN	01CE	PLOT	011D	PLOT1	0145	PLTD	000F	PLTS	000E
PTBUFF	010D	PUMSG	02A8	PUP	01C7	PX	011F	PY	0122
QRXBUF	006C	QRYBUF	00A0	QX	007E	QY	00B2	RX	0081
RY	00B5	SBUF	017B	SE	0182	SIZE	0180	TP	016E
XAXIS	007C	YAXIS	00B0						

# —BASIC Main Program—

BASIC compiler SB-7701 <X-YDEMO> page 1 07.09.81

```

000F    EXTERNAL IPLOT,PLOT,IMOVE,MOVE,PUP,PDOWN,XAXIS,YAXIS,CTYPE
000F    EXTERNAL CSIZE,SIZE,HOME,ANGL,MARK,ERCLR,DOTM,DOT0,DOT
000F    DIM D(1,255),E(50)
0042    DIM A(23),B(23)
005F    HOME : CSIZE : ANGL 0: DOT0
00A8    REM *FDOS NO SAKUGA*
00A8    REM * F *
00A8    MOVE 200,2400
00DD    IPLOT 400,0: IPLOT 0,-150: IPLOT -400,0: IPLOT 0,150
018C    IMOVE 50,-50: IPLOT 300,0: IPLOT 0,-50: IPLOT -300,0: IPLOT 0,50
0256    MOVE 200,2170: IPLOT 400,0: IPLOT 0,-150: IPLOT -230,0
0300    IPLOT 0,-220: IPLOT -170,0: IPLOT 0,370
038A    IMOVE 50,-50: IPLOT 300,0: IPLOT 0,-50
03FF    IPLOT -230,0: IPLOT 0,-220: IPLOT -70,0
047B    IPLOT 0,270
04A9    REM * D *
04A9    MOVE 630,2400: IPLOT 210,0
0505    A=840: B=300: C=2100: GOSUB 1100
0540    IPLOT -210,0: IPLOT 0,370: IPLOT 170,0: IPLOT 0,-220
05DC    A=810: B=150: C=2100: GOSUB 1000
060B    IPLOT -180,0: IPLOT 0,150: IMOVE 50,-50: IPLOT 160,0
06B5    A=840: B=250: C=2100: GOSUB 1100
06E4    IPLOT -160,0: IPLOT 0,270: IPLOT 70,0: IPLOT 0,-220: IPLOT 60,0
07AE    A=810: B=200: C=2100: GOSUB 1000
07D6    IPLOT -130,0: IPLOT 0,50: GOTO 1200
0836    1000 FOR I=- $\pi/2$  TO  $\pi/2$  STEP  $\pi/60$ 
0890        X=INT(A+B*COS(I)): Y=INT(C+B*SIN(I))
090A        PLOT X,Y
091F        NEXT I
092A        RETURN
0930    1100 FOR I= $\pi/2$  TO  $-\pi/2$  STEP  $-\pi/60$ 
0978        X=INT(A+B*COS(I)): Y=INT(C+B*SIN(I))
09DE        PLOT X,Y
09F3        NEXT I
09F9        RETURN
09FF    1200 REM * O *
0A05        X=0: Y=0: A=0: B=0: C=0: D=0: MOVE 1760,2100
0A69        A=1460: B=300: C=2100: D=300: GOSUB 1300
0AA1        IMOVE -50,0
0AC8        A=1460: B=250: C=2100: D=250: GOSUB 1300
0AF9        IMOVE -90,0
0B27        A=1460: B=160: C=2100: D=200: GOSUB 1300
0B58        IMOVE -50,0
0B7F        A=1460: B=110: C=2100: D=150: GOSUB 1300
0BB7        MOVE 1840,2350: GOTO 1400
0BF2    1300 FOR I=0 $\pi$  TO 2 $\pi$  STEP  $\pi/60$ 
0C28        X=INT(A+B*COS(I)): Y=INT(C+D*SIN(I))
0C8E        PLOT X,Y
0CA3        NEXT I: A=0: B=0: C=0: D=0: X=0: Y=0: RETURN
0CE5    1400 REM * S *
0CEB        FOR I= $\pi$  TO  $\pi*7/6$  STEP  $\pi/60$ 
0D32        X=INT(1960+120*COS(I)): Y=INT(2350+120*SIN(I))
0DA6        PLOT X,Y: NEXT I: X=0: Y=0
0DD3        A=1920: B=110: C=2010: GOSUB 1500
0E09        IPLOT -120,0: IPLOT 0,-50: IPLOT 140,0

```

```

0E85      A=1940: B=160: C=2010: GOSUB 1600
0EB4      FOR I=π*7/6 TO π*186/180 STEP -π/60
0F0C      X=INT(2030+135*COS(I)): Y=INT(2370+135*SIN(I))
0F87      PLOT X,Y
0F9C      NEXT I: I=0: X=0: Y=0: IMOVE -38,45
1010      IPLOT 150,0
1037      FOR I=π*8/9 TO π*7/6 STEP π/60
108D      X=INT(2030+85*COS(I)): Y=INT(2370+85*SIN(I))
10FA      PLOT X,Y
110F      NEXT I: X=0: Y=0
1127      A=1940: B=210: C=2010: GOSUB 1500
114F      IPLOT -190,0: IPLOT 0,150: IPLOT 170,0
11CB      A=1920: B=60: C=2010: GOSUB 1600
11F3      FOR I=π*7/6 TO π*8/9 STEP -π/60
1244      X=INT(1960+170*COS(I)): Y=INT(2350+170*SIN(I))
12AA      PLOT X,Y
12BF      NEXT I: X=0: Y=0: GOTO 1700
12DD      1500 REM * SUB A *
12E3      FOR I=π/6 TO -π/2 STEP -π/60
1325      X=INT(A+B*COS(I)): Y=INT(C+B*SIN(I))
138B      PLOT X,Y
13A0      NEXT I: X=0: Y=0: RETURN
13BE      1600 REM * SUB B *
13C4      FOR I=-π/2 TO π/6 STEP π/60
13FD      X=INT(A+B*COS(I)): Y=INT(C+B*SIN(I))
1463      PLOT X,Y
1478      NEXT I: X=0: Y=0: RETURN
1496      REM * DIAMOND *
1496      MOVE 3000,2050
14CB      1700 FOR Z=1 TO 23
14F1      A(Z)=INT(350*COS(2*π*(Z-1)/23+π/2)+3000)
158D      B(Z)=INT(-350*SIN(2*π*(Z-1)/23+π/2)+2050)
1621      NEXT Z
1627      FOR S=2 TO 11
1649      L=2-S
1655      X=A(23): Y=B(23)
1682      MOVE X,Y
1697      FOR I=1 TO 24
16B9      J=L+S
16C5      IF J<24 THEN 1800
16E7      J=J-23
16F3      1800 X1=A(J): L=J: Y1=B(J)
172A      A=X1-X: B=Y1-Y
1742      IPLOT A,B
1757      X=X1: Y=Y1
1769      NEXT I: NEXT S: X=0: Y=0: X1=0: Y1=0: A=0: B=0
17AB      MOVE 1650,1320
17E0      REM *PRINT " 3D-GRAPH"*
17E0      A$=" 3D-GRAPH"
1802      FOR I=3 TO 0 STEP -1
1830      MOVE 1650,1320
1857      ANGL I
1866      CTYPE A$
187D      NEXT I: A$=""
1891      REM * 3D-GRAPHIC *

```

```

1891      T=0: S=0
18A3      FOR L=0 TO 255
18BE      D(0,L)=-1: D(1,L)=-1: NEXT L
18F2      MOVE 100,250
1920      FOR Y=-180 TO 180 STEP 4
194E      FOR X=-180 TO 180 STEP 4
1975      IF (Y=-180)*(X=180) THEN 2600
19B3 1900 R=PI/180*SQR(X*X+Y*Y)
19FE      Z=100*COS(R)-30*COS(3*R)
1A47      A=INT((110+X/2+(16-Y/2)/2)
1AA8      B=INT((116-Y/2-Z)/2): B=192-B
1B04      IF (A<0)+(A>255) THEN 2000
1B39      IF D(0,A)=-1 THEN 2100
1B68      IF B<D(0,A) THEN 2300
1B93      IF B>D(1,A) THEN 2400
1BBE 2000 NEXT X
1BCA      IMOVE 0,0: T=0: S=0
1C03      NEXT Y
1C09      GOTO 2700
1C0F 2100 IF A=0 THEN 2200
1C2D      IF D(0,A-1)=-1 THEN 2200
1C68      IF D(0,A+1)=-1 THEN 2200
1CA3      D(0,A)=INT((D(0,A-1)+D(0,A+1))/2)
1D0F      D(1,A)=INT((D(1,A-1)+D(1,A+1))/2)
1D7B      GOSUB 2500: GOTO 2000
1D8E 2200 D(0,A)=B: D(1,A)=B: GOSUB 2500: GOTO 2000
1DD5 2300 GOSUB 2500: D(0,A)=B: IF D(1,A)=-1 THEN D(1,A)=B
1E42      GOTO 2000
1E48 2400 GOSUB 2500: D(1,A)=B: IF D(0,A)=-1 THEN D(1,A)=B
1EB5      GOTO 2000
1EBB 2500 REM *SUB DATA OUT *
1EC1      DX=100+7*A: DY=8*B
1EE5      MOVE DX,DY: PDOWN: PUP
1F0C      RETURN
1F12 2600 REM *SUB GENSUI *
1F18      FOR K=1 TO 50: E(K)=0: NEXT K
1F4D      FOR I=1 TO 50
1F68      E(I)=SIN(I*PI/12.5)
1FA4      NEXT I
1FAA      N=15
1FBA      FOR I=1 TO N
1FD5      D=5*I/N+5: G=(N-I+0.5)/N*4: O=DX: P=DY
2049      MOVE O,P
205E      FOR J=1 TO 50
2079      O=DX+E(J)*G*(50-J): P=P+D
20C0      PLOT O,P
20D5      NEXT J: NEXT I: MOVE DX,DY: GOTO 1900
20FC 2700 REM * SIN(X)/X *
2102      MOVE 2350,900
2130      XAXIS 87,12
2165      MOVE 2870,700
219A      YAXIS 200,4: MOVE 2350,900
21E8      FOR I=-6 TO 6 STEP 0.08
2216      IF I=0 THEN Y=1: X=0: GOTO 2800
2243      X=I*PI

```



```

224F      Y=SIN(X)/X
2264 2800  A=2870+INT(27.5*X+0.5)
229E      B=900+INT(400*Y)
22BF      PLOT A,B
22D4      NEXT I
22DA      MOVE 2350,1300: DOTM : MARK 1
2329      IPLOT 174,0: MARK 2: IPLOT 174,-200: MARK 3: IPLOT 174,-200: MARK 4
23ED      IPLOT 174,200: MARK 5: IPLOT 174,200: MARK 6: IPLOT 174,0
2492      DOT0
249B      MOVE 2350,700: IPLOT 0,800: IPLOT 1044,0: IPLOT 0,-800: IPLOT -1044,0
256C      MOVE 3100,800: SIZE 2: A$="XAXIS": CTYPE A$
25D7      A$="YAXIS": MOVE 2800,1300: ANGL 1: CTYPE A$: ANGL 0: A$=""
2668      REM * SHARP SIZE *
2668      MOVE 2550,300
2696      B$="SHARP "
26AA      FOR I=1 TO 15 STEP 5
26D1      SIZE I
26E0      CTYPE B$
26F2      NEXT I: B$=""
2706      CSIZE
270F      REM * CHARACTER SET *
270F      MOVE 400,150
2736      C$="1234567890ABCDEFGHIJKLMNPOQRSTUVWXYZ !#$%&'()*+,-./:*<?@?;:"
277C      CTYPE C$
278E      REM * DOT0 TYPE *
278E      HOME : PLOT 0,2500: PLOT 3590,2500: PLOT 3590,0: PLOT 0,0: IMOVE 15,15
2868      H=3560: V=2470: R=15
2891      FOR I=20 TO 60 STEP 20
28BF      DOT I
28CE      IPLOT 0,V: IPLOT H,0: IPLOT 0,-V: IPLOT -H,0: IMOVE R,R
296D      V=V-2*R: H=H-2*R
299D      NEXT I
29A3      HOME : IMOVE 60,60
29D3      DOT0 : IPLOT 0,V: IPLOT H,0: IPLOT 0,-V: IPLOT -H,0
2A66      D$="PEN UP DOWN"
2A7F      MOVE 2050,400
2AA6      CTYPE D$
2AB8      IMOVE 50,0
2ADF      FOR I=1 TO 5: PUP : PDOWN : NEXT I
2B12      CSIZE : DOT0 : ANGL 0: HOME
2B45      END

```

\*\* Compiler found no errors.